# **VASQUEZ-BEGGS**

The Vasquez-Beggs equation (VBE) is the easiest calculation tool to use. It is most appropriate for use on upstream operations, such as stock tanks at wellheads, oil and gas production batteries, and for "black oil" (a heavy, low-volatility oil approximated by a gas to oil ratio of less than 1750 cubic feet and API gravity less than 40 degrees). It is the default method required by KDHE for all facilities with flash emissions. This model only has eight input variables: API gravity, separator pressure (psig), temperature (°F), gas specific gravity, volume of produced hydrocarbons (bbls/day), molecular weight of the gas, VOC fraction of the emissions, and atmospheric pressure (psia). An example is attached (see attachment 1).

With the VBE, tank-flashing losses are calculated as total VOC's (only) and are not speciated into individual chemical compounds or HAPs. It has been shown that tank-flashing estimates of VOCs using the VBE may be considerably underestimated or overestimated, depending on the numerous variables that affect flash losses. The variability is more apparent when modeling tank-flashing near the wellhead, where the pressure drop is highest and liquid composition is more variable. The VBE model does not calculate standing or working losses from storage tanks.

## **HAP-Calc using VASQUEZ-BEGGS**

The HAP-Calc model uses the Vasquez-Beggs method to estimate VOC tank-flashing emissions, so KDHE will accept this analysis instead of spreadsheet calculations. In addition to estimating VOC tank-flashing emissions, the HAP-Calc program speciates HAP emissions. The HAP emissions can be estimated by entering site-specific data, or by using default program values. The HAP-Calc program runs in Windows format and costs about \$75 through the Gas Research Institute (GRI). Since it uses Vasquez-Beggs as the basis for its calculations, this program may err in the same way compared to process simulators.

# ENVIRONMENTAL CONSULTANTS and RESEARCH, Inc.

Environmental Consultants and Research, Inc. equation (EC/R) estimates the ratio of each component in the liquid phase versus the vapor based on the tank pressure and the mole fraction of the vapor flashed. The flash emissions from the tank are then calculated using that information, the tank throughput, the density of the hydrocarbon liquids, and the mass fraction of each component in the liquid. At pressures below 1.6 atm (~8.8 psig), emissions are assumed to approach zero and at pressures greater the 5.1 atm (~60.3 psig), another emission estimation is required. An example is attached (see attachment 2).

#### E&P TANKS

In addition to tank-flashing losses, the E&P Tanks program estimates tank working and standing losses. The model uses the Peng-Robinson equation of state to estimate tank-flashing losses and speciates between HAP emissions and VOCs. This model is best suited for upstream operations, such as stock tanks at wellheads and tank batteries common to several wellheads, although it will handle a broader range of API gravities (15-68).

The program costs about \$300 (in 2002) from the American Petroleum Institute (API) and tends to be more complicated than Vasquez-Beggs to run. Even though this model uses the Peng-Robinson equation of state, evaluations compared with process simulators give somewhat inconsistent results with variations in pressure inputs. It has been shown that the E&P Tanks model may also underestimate or overestimate VOC tank-flashing emissions, but not as much as the Vasquez-Beggs equations.

#### **DETERMINATION of the GAS OIL RATIO**

Determination of the hydrocarbon liquid gas oil ratio (GOR) can be obtained by collecting a pressurized sample upstream of the storage tank (i.e. separator dump line). The flashing losses/emissions can be determined by multiplying the GOR by the throughput of the tank. An extended hydrocarbon analysis of the flash gas from the sample should also be conducted to identify the concentrations of the individual components of the tank's flash emissions.

### PROCESS SIMULATORS

Process simulators are computer models that use EOS and mass energy balances to simulate petroleum processes for a variety of engineering purposes. There are several different manufacturers of process simulators (HYSIM, HYSIS, WINSIM, PROSIM, etc.) each utilizing similar basic principles. Process simulators are mainly used in process design and have been demonstrated to accurately predict natural gas and petroleum processes. Process simulators can be used to estimate flash emissions and speciate these emissions. Required inputs may include an extended pressurized condensate analysis as well as other parameters (e.g. temperature, pressure, and flow) for the process being simulated. Process simulators are not constrained by API gravity. This method pf estimating potential flash emissions can be very expensive (\$13,000 a year to own) and complicated and is expected to be more accurate when estimating flashing losses/VOC emissions from hydrocarbon storage tanks than other emissions estimation methods.

#### DIRECT MEASUREMENT of EMISSIONS

Actual testing of emissions from the tanks also can be performed to determine flash emissions. Since, there are no currently approved U.S. EPA reference methods that are developed specifically fro measuring emissions from storage tanks, approved reference methods and modified reference methods or other approved methods may be used to characterize and determine these emissions, with prior approval from KDHE. However, it should be noted that such testing is just a snapshot of the emissions and should be used in conjunction with a safety factor to establish emission limits.

Note: The following table shows values that have been accepted as default values for VBE calculations:

Inputs	Units	Default Value		
Stock Tank API Gravity	API	78.0		
Separator Temperature	°F	60.0		
Separator Gas Specific Gravity		0.9		
Stock Tank Gas Molecular Weight	lb/lb-mole	49.0		
VOC Fraction of the Stock Tank Gas	Fraction	0.8		
Atmospheric Pressure	psia	14.7		

Other values may be used as long as they have been obtained from site-specific data collection or are based on a representative sample.

The referenced method summaries are from New Mexico and Oklahoma. Attachments 1 and 2 for example calculations can be found on the Oklahoma website http://www.deq.state.ok.us/AQDnew/resources/Calculations11.xls.

	Penn	it No.:				•
Company Name:	Date					
Facility Name:	,					
· · · · · · · · · · · · · · · · · · ·	pound Emission Calcul	ation for Flashin	<u> </u>			
Vasanez - Beggs So	ution Gas/Oil Ratio Cor	relation Method				
<b>Value</b> 100		Oil Parios For C	rode Oil Fac	ilities)		
(For Estimating VOC Flashing Emissio	os, Using Stock Tank Gas	Oll Kanos I of -		•		
· ·		CONST	RAINTS:		TOAG	WARNING
INPUTS:	78 API	16	>API>	58 5250	(pgia)	WARNING
Stock Tank API Gravity Separator Pressure (psig)	33 P	50 70	-P+Patm:	295	(PF)	WARNING
Townershire (F)	69 Ti	0,56	≻SGÞ	1.18	MW/28.9	ok
Constant Gas Gravity at Initial Condition	0.9 SGI	None	>Q>	None	(BOPD)	
Stock Tank Barrels of Oil per day (BOLL		18	>MW>	125	lb/lb-mol	
Ctock Took Gas Molecular Weight	49 MW 0.8 VOC	0.5	>Vot>	1.00	Fraction	
Fraction VOC (C3+) of Stock Tank Gas	14.7 Patm	20	> Rs >	2070	(scf/STB)	ok
Atmospheric Pressure (psia)	23.7) 2.2					<b>-</b>
		om(Pi/1147)				
SGx = Dissolved gas gravity at 100 psig = SGi [1.	0+0,00005912*API-11-1	DOB(X P. Z.Z)				
_						<b>-</b>
SGx = \$1.00.81			Docum	ent Notes	•	
Rs = (C1 * SGx * Fi^C2) exp ((C3 * API) / (Ti	+ 460))					
KD - (O2	uid at pressure of interest					1
Where: Rs Gas/Oil Rand of Rd SGx Dissolved gas gravi	tv at 100 psig		41			
		****	-			
A DT A DT Gravity of light	id hydrocarbon at mai co	Darpon				
Ti Temperature of init	ial condition (F)	·····				
Constants						Į
Constants PAPI Grav	ity					Ì
≥= 30   ≥= 30	Given API					
C1 0.0262 0.017	8 140.0178					
C2 1.0927 1.18	7 = 1388		1			
C3 <u>25.724</u> 23.93	23.931					
for P+	Patm = 47	.7				
$Rs = 55001 \operatorname{scf/bbl}  for P +$						
	+ + + + + + + + + + + + + + + +					
THC = Rs * Q * MW * 1/385 scf/lb-mole * 36	5 D/11 - 1 tom/2000 xxxx				<del></del> 1	
					{	•
Solution Gas/Oil R	atio (scf/STB)					
On Bushing Par	* (bb)/day)					
	of Stock Tank Gas (Ib/Ib- le of gas at 14.7 psia and	68 F (WAQS&R	Std Cond)	r		
385 Volume of 1 lb-ma	ote OI gas at 14.7 pour and					•
Version						<del>-</del>
THC = 2229 TPY						
	* **					
VOC = THC * Frac. of C3+ in the Stock Tan	k vapor		_			

VOC = TT 183 TPY from "FLASHING" of oil from separator to tank press

EC/R Algorithm (Akin Battye, 1994)

Tom Atkin & William Battye, 1994. Memorandum to Martina E. Smith, U.S. EPA.

Environmental Consultants and Research, Inc. 10/18/94 Durham, NC

For flashing losses from tanks based on the pressure drop of the process stream.

Derived from the behavior of the liquid stream based on changes in stream compositions and pressure.

Method assumes that the equilibrium of the liquid and vapor are reached at STP and the tank is at STP.

Valid for liquid streams between pressures of 1.64 and 5.10 atmospheres. (23.5 psia to 75 psia)

Pressure of Separator Throughput of Condensate Specific Gravity of Condensate Vapor Pressure of Condensate	33.00 psig 19.30 bbl/day 78.00 API 7.48 psia	MAXIMUM VALUE DEFAULT VALUES DEFAULT VALUES	61 psig 78 API 8 psia
Flashing Losses/Emissions	4.07 lb/hr 17.84 TPY		

If the composition of the liquid coming from the separator are known enter here for a more comprehensive emission breakdown.

Mole Fraction	W	Mass Fraction		Flashing losses/emissions			
	0.000	28.0	0.0	0.000			
X <sub>0002</sub>	0.001	44.0	0.1	0.001			
	0.024	16.0	0.4	0.004			
Xcs	0.019	30.1	0.5	0.005	VOC	<b></b>	PY
χœ	0.055	44.1	2.4	0.025	Ecs	1.25	5.51
X <sub>CS</sub>	0.045	5B.1	2.6	0.028	Ece	0.49	2.15
X <sub>not</sub>	0.015	58.1	0.9	0.010	Ece	0.25	1.07
XIDA	0.03B	72.1	2.7	0.029	Ecs	0.17	0.73
X <sub>nos</sub> .	0.034	72.1	2.4	0.026	Ecs	0.20	0.89
X <sub>ICS</sub>	0.054 0.081	84.2	6.8	0.073	Ecs	0.09	0.37
Xos	0.229	100.2	23.0	0.244	Ecr	0.15	0.68
Xer	0.287	114.2	32.8	0.348	Eca	0.07	0.33
X <sub>CS</sub> X <sub>CO+</sub>	0.070	142.3	10.0	0.106	Eco	0.00	0.00
HAPs	n 000	78.1	0.3	0.003	Eberzene	0.00	0.01
XBenzena	0.003	92.1	2.6	0.028	Evoluene	0.00	0.01
XTaluere	0.028	105.2	0.0	0.000	Ephythercan	0.00	0.00
XEmylerizate	0.000	106.2	3.4	0.036	Exylene	0.00	0.02
Xxytene	0.032		3.1	0.032	E <sub>n-Hexpute</sub>	0.04	0.17
X <sub>s-Hexane</sub>	0.035	86.2	3.1	<b>5</b>			
TOTALS	0.999		94.07	1.00		2.73	11.95